


REAR MEDIA CONTROL FROM THE TOUCH SCREEN



E157297

Touch **Rear media** on the Audio/video home menu to select the Rear media control screen.

1. Information display.
2. Touch to select the left-side rear screen.
3. Touch to synchronise both screens. Then select the source to be synchronised.
***Note:** Pressing the synchronise button will not synchronise a source already selected.*
4. Touch to select the right-side rear screen.

5. **Limo mode:** Touch to turn Limousine mode ON/OFF.
When Limousine mode is turned ON, the rear passengers will have control of the total cabin audio system and any shared sources via the remote control.
6. **Lock:** Touch to lock or unlock the rear media remote.
7. **System:** Touch to turn the selected rear screen/s ON/OFF.