
Front seats

MANUAL SEATS





Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

- 1. Forward and rearward adjustment.
- 2. Height adjustment.
- 3. Seatback angle adjustment.
- 4. Head restraint adjustment (where fitted).