

# Index

- warning lamp.....46
  - Door mirrors.....56
    - blind spot monitor.....58
    - closing vehicle sensing.....60
    - sensors.....61
  - Door transceiver
    - assistance.....64
    - erase all programming.....63
    - garage door opener.....62
    - programming.....62
    - programming a single button.....63
    - programming the garage door opener.....62
    - rolling code device programming.....63
  - Double locking.....12
  - Drive away locking.....10
  - Drive selector
    - malfunction.....91
  - Drive selector fails to elevate.....91
  - Driving
    - ACC automatic switch-off.....110
    - ACC driving hints.....111
    - ACC emergency braking.....114
    - ACC follow mode.....109
    - ACC forward alert.....113
    - ACC gap change.....109
    - ACC malfunction.....112
    - ACC queue assist.....110
    - ACC radar detection beam issues.....112
    - ACC set speed and follow mode
      - override.....110
    - activating intelligent stop/start.....87
    - adaptive cruise control.....108
    - after a collision.....252
    - aids
      - lane departure warning.....122
      - traffic sign recognition.....121
    - arduous conditions.....195
    - before starting.....252
    - blind spot monitor.....58
      - closing vehicle sensing.....60
    - blind spot monitor messages.....61
    - brake control with ABS.....95
    - brakes important information.....95
    - daily checks.....195
    - deactivating intelligent stop/start.....87
    - DSC active warning lamp.....44
    - dynamic mode.....92
    - electronic brake force distribution.....95
    - emergency brake assist.....95
    - forward alert.....113
    - forward alert warning lamp.....46
    - gear shift warning lamp.....45
    - low oil pressure.....43
    - park assist
      - park out.....104
    - park assist limitations.....105
    - park assist troubleshooting.....106
    - rain sensor.....53
    - resume ACC follow mode.....111
    - resume ACC set speed.....111
    - selecting park assist.....103
    - sitting correctly.....18
    - steep slope control with ABS.....95
    - using ACC.....108
    - using cruise control.....107
    - weekly checks.....195
  - Driving abroad
    - beam pattern.....49
    - headlamps.....49
  - Driving position memory.....18
  - Driving short distances
    - diesel particulate filter (DPF).....196
  - Dual view.....147
    - controls.....147
  - Dynamic mode.....92
  - Dynamic stability control (DSC)
    - DSC active warning lamp.....44
    - DSC off warning lamp.....44
    - switching off.....92
    - switching on.....92
- ## E
- Easy route.....166
  - Eco-data controls.....88
  - Effects of battery disconnection.....220
  - Electric parking brake.....96
  - Electric seats.....17
    - position memory.....18