
## **Navigation system**

## **MAP SPLIT SCREEN**



- Compass (always indicates north): Press to select: north up, heading up or bird's eye map style.
- TMC (Traffic Message Channel) signal:
  Without a diagonal bar, a signal is being
  received; with a diagonal bar, a signal is not
  being received. The icon will also change
  colour depending on the status of traffic on
  the route.
- 3. Next direction display: When Junction map view has been switched off, touch the icon to view again.
- 4. Current vehicle position and direction.
- 5. Right map view, scale/zoom setting.
- 6. Current location.
- 7. GPS signal indicator: The indicator is only displayed when there is no reception.
- 8. Screen mode.

- 9. Left map view, scale/zoom setting.
- **10.** Opens the Navigation menu; 1 of 2 screens.
- **11.** Distance/time/ETA (Estimated Time of Arrival) to the destination.
- **12.** TMC event (traffic congestion).



Touch to close the Junction and Motorway junction view. The previously displayed map is shown after closing.

## MAP AUTO ZOOM

When under guidance, the map zooms in automatically when approaching a junction or motorway junction.

1. From the map screen, touch the left map view, scale/zoom soft key.