## Portable media

- From the Home menu, select Audio/Video, then My Music.
- 4. Touch Bluetooth.
- 5. A menu will appear. Select Change device.
- 6. Select Vehicle to device option.
- Identify your device from the displayed list and select the corresponding Pair and connect option.

**Note:** If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

- 8. When prompted, enter the PIN (Personal Identification Number) code into your device. See your device's operating instructions for more information.
- Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music, Bluetooth view.

Note: Due to the duration of a Bluetooth® wireless technology device search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® wireless technology devices. This setting can be changed within Set-up, Screen, Time out home.

## CHANGING/DISCONNECTING A DEVICE

- 1. From the **Bluetooth** menu, select **Change** device.
- Select Disconnect. A confirmation pop-up will appear and then you will be given the option to Search new or select a different device from the list of paired devices.