ELECTRONIC TRACTION CONTROL (ETC)

ETC operates in conjunction with Dynamic Stability Control (DSC) and is designed to assist when 1 or more wheels have lost traction, wheel spin for example.

If a wheel loses traction, ETC will operate the brake on that wheel and may also manipulate the engine output, until the wheel regains traction. The amber DSC warning lamp in the Instrument panel will flash to inform the driver that ETC is operating.