

Index

Fog lamps	
warning lamps	
front.....	46
rear.....	45
Follow	
override.....	110
Follow mode	
entering.....	109
gap change.....	109
gap changing.....	109
override.....	111
resume.....	111
Forward alert.....	113
Forward alert in ACC	
object detection.....	113
Forward alert warning lamp.....	46
Front airbags.....	37
Front climate control.....	71
Front parking aids.....	98
system fault.....	99
Front wipers.....	52
winter park position.....	206
Fuel and refuelling.....	192
consumption.....	193
diesel.....	191
diesel fuel sulphur content.....	191
ethanol.....	190
filler flap.....	192
fuel specification.....	193
methanol.....	190
methyl tertiary butyl ether (MTBE).....	190
misfuel device.....	192
octane rating.....	190
petrol.....	190
reformulated gasoline.....	191
running out.....	191
safety precautions.....	190
tank capacity.....	193
Fuel burning heater.....	73
Fuel consumption.....	193
combined cycles.....	194
extra-urban cycle.....	193
urban cycle.....	193
Fuel gauge.....	40
Fuel system.....	200
Full screen view for video.....	146
Fuses	
changing.....	223
engine compartment fuse box.....	224
locations.....	222
luggage compartment fuse box.....	228
passenger compartment fuse box.....	226
G	
Garage door opener.....	62
assistance.....	64
entry gate.....	63
erase all programming.....	63
programming.....	62
programming a rolling code device.....	63
programming a single button.....	63
Gearbox	
automatic.....	89
drive selector fails to elevate.....	91
fault.....	91
gear shift warning lamp.....	45
manual.....	91
General program.....	115
Glass cleaning.....	209
Global closing.....	13
Global opening.....	6
Glow plugs	
warning lamp.....	45
Gradient release control	
ascent brake release.....	118
Grass/gravel/snow.....	115
H	
Handbook symbols.....	2
Handbrake.....	96
Hands free parking.....	104
park assist limitations.....	105
park assist troubleshooting.....	106
selecting park assist.....	103
Hands free phone.....	188
Headlamps.....	47
adaptive.....	49