
STANDARD AUDIO SYSTEM CONTROLS



E150340

Sustained exposure to high sound levels can damage your hearing.

1. Press to switch on/off.

   Note: *The radio will switch off automatically after approximately 10 minutes if the ignition is turned off.*
   Rotate to adjust the volume level.

   Note: *The maximum volume level will be restricted if the audio unit is used with the engine switched off.*

2. **MENU** button:
   - Audio settings
   - Clock settings
   - Language

3. **OK** and navigation menu control:
   Use the navigation control to move to any menu cursor/highlight. When the required option is highlighted, press the **OK** button to select.

4. Parking aid.

5. Audio Information display.

6. Keypad.

7. **INFO**: Traffic/News information.

8. **PHONE** menu.

9. **AUX** input select.

10. **RADIO**: Waveband select (FM, FMAST, AM, AMAST).
    When DAB is fitted, select for DAB1 or DAB2.

11. **CD** menu.

12. CD loading slot.

13. Seek up:
    - Short press to select the next radio station upward in frequency or to select the next track on chosen audio source.
    - Long press to enter radio manual seek mode or to scan forward through a CD track. In radio manual seek mode further short presses will change the frequency in single steps.

14. CD eject button.

15. Seek down: