### Garage door opener

- Press and hold the programmed garage door opener button and observe the indicator lamp.
  - If the indicator lamp illumination is continuous, programming is complete and your device should operate when the garage door opener button is pressed and held for approximately 1 to 2 seconds and then released.
  - If the indicator lamp blinks rapidly for 2 seconds and then illuminates continuously, proceed with the following programming instructions for rolling code device equipment.

#### TO ERASE ALL PROGRAMMING

For first time programming, make sure the engine is switched off:

- 1. Make sure the ignition is on (but with the engine switched off).
- 2. Press and hold the 2 outer buttons on the transceiver in the rear view mirror. Keep the buttons pressed until the indicator lamp begins to flash (this will take approximately 10 seconds), then release the buttons.

All memories in the garage door opener have now been cleared.

**Note:** Do not perform this procedure when programming the additional garage door opener buttons.

# ROLLING CODE DEVICE EQUIPMENT PROGRAMMING

**Note:** The assistance of a second person, may make the following steps quicker and easier. Once the button has been pressed there are only 30 seconds in which to complete Step 3.

 At the garage door opener receiver (motor head unit) in the garage, locate the learn or smart button/switch.

- The name of the button or switch may vary between manufacturers.
- 2. Press and release the learn or smart button.
- Return to the vehicle and firmly press and hold the programmed garage door opener button for 2 seconds and release.
- Repeat the press, hold, release sequence 3 times to complete the programming process.

The garage door opener in the rear view mirror should now activate the rolling code device.

## REPROGRAMMING A SINGLE GARAGE DOOR OPENER BUTTON

To programme a device to a previously programmed button:

- Press and hold the desired pre-programmed garage door opener button for at least 20 seconds, but no longer than 30 seconds, until the indicator lamp begins to flash.
- 2. Without releasing the rear-view mirror button, position the hand-held transmitter approximately 50 to 150 mm (2 to 6 inches) away from the transceiver in the rear-view mirror, keeping the indicator lamp in view.
- **3.** Carry out Step **3** of **Programming**.

### **ENTRY GATE PROGRAMMING**

The technology of some entry gates requires you to press and re-press (cycle) the hand-held transmitter button every 2 seconds during programming.

Continue to press and hold the desired rear-view mirror button while you cycle your hand-held transmitter until the indicator lamp flashes rapidly.