Infotainment (Standard)
adaptive volume control....178
alternative frequencies....181
automatic station retune....180
CD repeat and shuffle....186
CD track selection....186
clock settings....182
connecting portable media devices....187
controls....177
DAB messages....184
DAB radio....182
DAB radio ensemble seek....182
DAB radio manual tuning....183
DAB radio presets....182
DAB service list....183
display language....182
loading a CD....185
MP3 files playing....186
news information....181
portable media connections....186
radio controls....179
radio preset buttons....180
radio station autostore....180
radio station lock....180
servicelink....183
tone....178
traffic announcement volume....181
traffic information....181
Instrument panel....40, 210
display units....42
fuel range....42
lamp test....43
menu....40
driving features....40
instrument display....40
trip computer....40
vehicle set-up....40
warning lamps....43
warning messages....41
Intelligent stop/start
activating....87
deactivating....87
Intelligent stop/start warning lamp....46
Interior cleaning....209
airbag covers....210
carpets and mats....210
Interior lamps....50
ambient lighting....51
bulb changing....200
bulb specification....262
intensity....51
types....50
Interior locking....15
Interior protection
temporary disabling....14
ISOFIX anchor points....33
ISOFIX installation....33

J

Jump starting
connecting a starting aid....219
connecting jump leads....218

K

Keyless entry....6
Keyless locking....14
Key transmitters....7

L

Label locations....253
Lamps....47
auto lamps wiper detection....49
bulb changing....200
bulb specification....262
condensation....49
test....43
TPMS warning lamp....45
warning lamps....43
xenon headlamps....201
Lane departure warning....122
Leather cleaning....209
Lighting
ambient lighting....51
interior lamps intensity....51
interior lamps locations....50
Load carriers
roof mounted....78