4. When the new parts have been fitted, turn the ignition off. This will return the wipers to the park position.

## **WINDOW RESET**

If the battery is disconnected or the power supply is interrupted, the windows must be reset.

Once the power supply is restored, reset as follows:

- 1. Close the window fully.
- 2. Release the switch, then lift it to the close position and hold for 1 second.
- 3. Repeat the procedure on each window.