
AUDIO/VIDEO CONTROLS



E153721

⚠ **In the interest of safety, only operate, adjust or view the system when it is safe to do so.**

⚠ **Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.**

1. Press to switch the audio system on/off.

   Note: *The audio system will operate with the ignition on or off, but will always switch off when the ignition is switched off. Switch the audio on again if required.*
   Rotate to adjust volume level.

   Note: *If volume is turned to zero while a Compact Disc (CD) is playing, the CD will pause play. Play will resume when a greater volume is selected.*

2. **SETUP**: Press for direct access to the **Settings** menu. When Park assist is fitted, the icon is changed and the button will turn Park assist on and off. The **Settings** menu is then accessed via the Touch screen.

3. **HOME MENU**: Press for direct access to the **Home menu** screen.

4. Touch screen

5. **MODE**: Press this button repeatedly to scroll through all the audio/video sources. When Dual view is fitted, the button icon is changed and the button will turn Dual view on and off.

6. **AUDIO VIDEO**: Press for direct access to the **Audio/Video** menu.
   Audio/Video options can include Radio, DAB Radio, My music, My video and Rear media.
   My music consists of CD, Stored CD, MP3, USB, iPod® and AUX.
   My video includes CD/DVD, USB, iPod® and TV.

7. CD or Digital Versatile Disc (DVD) loading slot.