INTERIOR LIGHTS



- · OFF position permanently off.
- Central position automatic operation:
 When a door is opened the lamps will
 illuminate for 15 seconds after the door is
 closed or until the starter switch is turned
 on.

The tail-door of a station wagon will also activate the interior lamps.

Note: If a door remains open while the switch is in automatic position, the lamps will extinguish after approximately 8 minutes.

• ON position - permanently on.