
## REAR MEDIA CONTROL FROM THE TOUCH SCREEN



SL2652

Touch **Rear media** on the Audio/Video home menu, to select the Rear media control screen.

**Note:** When the main Rear media control screen is displayed on the Touch screen, the Rear media remote control will be locked out.

- 1. Information display.
- 2. Touch to select the left rear screen.

Sync: After selecting a source (see items 2 and 4), touch Sync to synchronise both screens. Both screens will then display the selected source.

**Note:** If both screens are already synchronised, the **Sync** button will be greyed out.

4. Touch to select the right rear screen.