

roof rack weight.....	274	Wi-Fi	
saloon.....	274	inControl connection.....	178
sportbrake.....	274	Windows	
tow ball/hitch.....	92	anti-trap protection.....	73
towing.....	92	driver controls.....	
vehicle weights.....	274	operation.....	72
Wheel balancing.....	206	reset.....	217
Wheel changing		sunroof blind.....	72
important information.....	260	sunroof operation.....	72
locking wheel nuts.....	256	sunroof reset.....	217
recommended process.....	257	Winter park position.....	217
safety warnings.....	254	Winter tyres.....	245
spare wheel.....	254	Wipers and washers.....	60
temporary spare wheel.....	256	driver controls.....	
tilt sensor.....	257	fluid level.....	225
tool kit.....	254	rain sensor.....	61
use of spare tyre.....	260	speed-dependent mode.....	61
Wheel chocks use.....	256	winter park position.....	62
Wheels and tyres			
age degradation.....	245	X	
changing a tyre.....	249	Xenon headlamps.....	213
checking the pressures after a repair.....	252		
flat spots.....	244		
full size replacements.....	248		
Indian regulations.....	246		
pressures.....	242		
puncture repair.....	250		
puncture repair safety.....	250		
repair kit.....	250		
repair kit use.....	250		
repair procedure.....	251		
replacements.....	244		
snow chains.....	245		
temporary use spare.....	249		
TPMS.....	247		
TPMS warning lamp.....	52		
tyre care.....	242		
tyre speed ratings.....	242		
tyre wall markings.....	241		
valves.....	244		
wheel alignment.....	278		
winter tyres.....	245		
Wheel spin.....	110		