


REAR MEDIA CONTROL FROM THE TOUCH SCREEN



E161610

Touch **Rear media** on the Audio/video home menu to select the Rear media control screen.

Note: When the main Rear media control screen is displayed on the Touch screen, the Rear media remote control will be locked out.

1. Information display.
2. Touch to select the left rear screen.

3. **Sync:** After selecting a source (see items 2 and 4), touch **Sync** to synchronise both screens. Both screens will then display the selected source.

Note: If both screens are already synchronised, the **Sync** button will be greyed out.

4. Touch to select the right rear screen.
5. **Limo Mode:** Touch to turn Limousine mode On and Off.