
AUTOMATIC TRANSMISSION



The gear selector status is displayed in the Message centre. See **46**, **INSTRUMENT PANEL**. Also the appropriate LED indicator, on top of the gear selector, will illuminate to confirm selection.



Park (P) should only be engaged when the vehicle is stationary. If any other gear position is selected while the vehicle is stationary, the vehicle can move unexpectedly, which may result in death or serious injury. Always make sure the parking brake is applied after engaging P.

Never select **P** while the vehicle is in motion. Doing so can result in serious transmission damage.

Note: P cannot be selected by manually moving the gear selector.

Press the park button to select Park (P).
 The park button LED indicator lamp will illuminate to confirm.

Note: P can be selected from any gear selector position.

Select **P** before switching off the engine.

Note: If the engine is switched off with Neutral (N) selected, the system will wait for 10 minutes before selecting P. This procedure is to allow the vehicle to be conveyed through a car wash only and should not be used for vehicle recovery purposes. See 264, TRANSPORTING THE VEHICLE

 When the vehicle is stationary, depress the brake pedal prior to selecting Drive (D), Neutral (N) or Reverse (R).