
Child safety



Your vehicle is equipped with anchorage points on the back of the second row seat frames. These should be used to attach straps from child seats or restraint systems.

- Install the child restraint securely in one of the rear seating positions.
- Pass the tether strap over the seat back and beneath the head restraint for the outer seat positions.

Note: For the centre seat position, pass the tether strap over the fixed head restraint.

- Attach the tether strap hook to the tether anchor point on the back of the seat. Make sure that the tether strap hook is facing the correct way (see illustration).
- Tighten the tether strap according to the child restraint manufacturer's instructions.

BOOSTER SEATS

In a situation where a child is too large to fit into a child safety seat but is still too small to safely use just the 3 point belt, a booster seat is recommended for maximum safety. Follow the manufacturer's instructions for fitting and use, then adjust the seat belt to suit. See **36**, **CHILD SEAT POSITIONING**.

The vehicle head restraint may need to be removed to accommodate all adjustments of the child restraint. See **25**, **HEAD RESTRAINT REMOVAL**.