LOCKING AND ARMING THE ALARM

Before exiting the vehicle, always make sure that the gear selector is in the Park (P) position, the engine is turned off, the parking brake is applied and the Smart key is removed from the vehicle.

Press the lock button on the Smart key briefly, to lock the vehicle and activate the perimeter alarm. The hazard warning lamps will flash to confirm.

The vehicle alarm will sound if:

- The hood, tailgate or a door are opened.
- The stop/start button is pressed without a valid key present.

KEYLESS LOCKING

NOTICE

The vehicle will not lock automatically.

NOTICE

The Smart key may not be detected if it is placed within a metal container, or if it is shielded by a device with a back-lit LCD screen such as a smart phone, laptop (including in a laptop bag), games console etc.

Note: Loose coins in the same pocket as the Smart key may also affect its detection.



E149763

Note: Keyless locking will activate only if the Smart key is detected outside the vehicle. If no Smart key is present, no locking will occur.

 To lock the vehicle, touch only the Keyless locking sensor (1) once without grabbing the door handle.

Note: Do not place your fingers around the back of the door handle while touching the sensor. Doing so will prevent the vehicle from locking.

 The hazard warning lamps will flash once to confirm locking and the power-fold mirrors will fold in (if enabled).

Note: When locking the vehicle via Keyless locking, if a valid key is not present, one or more of the doors, the hood or the tailgate is not fully closed, or the ignition is ON, the vehicle will NOT lock. There will be NO audible mislock error warning. The hazard warning lamps will NOT flash and the door mirrors (if enabled) will NOT fold in. Check that all of the doors, the hood and the tailgate are closed properly. Make sure that the ignition is turned OFF and lock the vehicle again. If the mislock persists, consult a Retailer/Authorized Repairer.

GLOBAL CLOSING

Make sure that no children, pets, or obstructions are in any open aperture before operating global closing. Safety mechanisms are in place to prevent serious injury, however injuries can still occur.

With a valid Smart key present, press and hold the keyless locking sensor (if fitted) on any exterior door handle. The vehicle will lock and the perimeter alarm will be activated immediately. After approximately 3 seconds, any open windows will begin to close.