

- parking sensors.....131
- seat belts.....229
- sensors and cameras.....227
- under body.....227
- closing the bonnet.....224
- daily checks.....221
- diesel particulate filter (DPF).....221
- dynamic response fluid level.....234
- engine compartment fuse box.....241
- engine coolant level.....232
- engine oil level.....230
- fuel system.....223
- fuse box (passenger compartment).....243
- jump starting.....237
- label locations.....277
- lubricants and fluid specifications.....280
- luggage compartment fuse box.....246
- oil top up.....231
- running-in.....220
- smart key battery.....11
- tyre repair kit.....259
- tyre repair procedure.....260
- using a starting aid.....237
- washer fluid level.....234
- washer jets.....226
- weekly checks.....221
- wheel balancing.....221
- Manual seats
  - head restraint removal.....25
  - head restraints.....25
- Map.....204
  - auto zoom.....200
  - split screen.....200
- Massage seats.....78
  - controls.....22
- Memory seats.....18
- Message centre display units.....45
- Methanol.....214
- Mirrors
  - blind spot monitor.....62
    - closing vehicle sensing.....64
    - sensors.....65
  - dip when reversing.....61
  - driver controls.....
  - exterior mirrors.....60
- Misfuel device.....216
- Motorway entry/exit
  - route setting.....204
- Mounting point dimensions
  - for powered tow bar.....109
  - for tow ball with multi height plate.....107
- Mpg.....218
- Mud ruts.....149
- N**
- Navigation
  - Arabic language.....206
  - automatic route learning.....202
  - avoid points.....202
  - destination entry.....201
    - search area.....201
  - destination entry by postcode.....203
  - easy route.....202
  - emergency contacts.....204
  - favourite locations.....203
  - home location.....203
  - legals.....209–211
  - licence terms.....210–211
  - licensing.....210–211
  - map.....204
    - auto zoom.....200
    - split screen.....200
  - menu.....198
  - motorway entry/exit selection.....204
  - off-road
    - new route.....208
    - route options.....208
    - routes.....208
    - selecting compass view.....209
    - using a stored route.....208
  - operating.....196
  - overview.....196
  - points of interest (POI).....204–205
    - categories/sub-categories.....205
    - search.....205
  - previous destinations.....204
  - quick POI selection.....203
  - restore defaults.....203