








WHEEL CHANGING SAFETY

Before raising the vehicle or changing a wheel, make sure that you read and comply with the following warnings:

-  **Always find a safe place to stop; off the highway and away from traffic.**
-  **Make sure that the vehicle and jack are both on firm, level ground. Do not jack the vehicle if it is over a metal grating or manhole cover.**
-  **Apply the Electric Parking Brake (EPB), and engage Park (P).**
-  **Make sure that the Air suspension is set to Off-road height.**
-  **Switch on the hazard warning lamps.**
-  **Make sure that the front wheels are in the straight ahead position.**
-  **Disconnect any trailer/caravan from the vehicle.**
-  **Make sure that all passengers and animals, are out of the vehicle and in a safe place away from the highway.**
-  **Place a warning triangle at a suitable distance behind the vehicle; facing towards oncoming traffic.**