


ELECTRIC SEATS



E161562



Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

Note: This diagram covers all electric seat controls. Not all of these controls apply to all seats.

1. Cushion length.
2. Bolster inflate/deflate.
3. Lumbar support.

4. Seat upper back angle.
5. Seat back angle.
6. Head restraint height.
7. Seat height.
8. Forward and rearward position.
9. Cushion tilt.

The front seats may also have: