


INSTRUMENT PANEL MENU



E138989

A number of vehicle features and display settings may be configured via the Instrument panel menu.

To display and navigate through the Instrument panel menu, operate the menu control on the steering wheel.

1. Steering wheel menu control.
2. Close and return to the **Main Menu**.
3. Access the vehicle's **Driving Features** menu.
4. Access the **Trip Computer** menu.
5. Access the **Instrument Display** menu.
6. Access the **Vehicle Set-Up** menu.
7. Access the vehicle's **Service Menu**.

Note: Only available before the engine starts.

Digital Speedometer

A digital speedometer is available in some markets. Depending on market specification, the driver may choose to turn the digital speedometer on or off, or change the units from imperial to metric. If available, the digital speedometer can be accessed through the **Digital speedometer** option in the Instrument panel menu.

WARNING AND INFORMATION MESSAGES



Do not ignore warning messages; take appropriate action as soon as possible. Failure to do so, may result in serious damage to the vehicle.

For information regarding the individual messages, their meanings, and any action required, please refer to the relevant section within this handbook.

If more than 1 message is active, each is displayed in turn for 2 seconds in order of priority.

Note: Messages are displayed in order of importance. High importance warning messages are given the highest priority.

Warning messages may be accompanied by an audible warning, and the message text may have the handbook symbol next to it. Warning messages are displayed until the condition causing the fault is rectified, or the message is suppressed using the **OK** button on the steering wheel. If a message is suppressed, an amber or red warning icon will remain illuminated until the cause of the message is rectified.

TRIP COMPUTER

The computer memory stores data for a journey, or a series of journeys, until it is reset to zero.