

top up.....	85
specifications.....	115
washer fluid.....	84
check.....	84
specification.....	84
Fog lamps	
warning lamps	
rear.....	30
Front climate control.....	32
Front wipers.....	24
Fuel and refuelling.....	66
consumption.....	68
diesel.....	65
diesel fuel sulphur content.....	65
filler flap.....	66
fuel filler cap.....	66
running out.....	65
safety precautions.....	65
Fuel consumption.....	68
Fuel cut-off switch.....	105
Fuel filler cap.....	66
Fuel gauge.....	28
Fuel system.....	71
Fuel tank	
capacity.....	114
Fuse box	
passenger compartment.....	92
Fuses	
changing.....	91
locations.....	91
passenger compartment fuse box.....	92
secondary fuse box.....	93
G	
Gearbox	
differential lock.....	46
differential lock wind up.....	46
driver controls.....	
manual.....	45
stationary range changing.....	45
transfer gearbox.....	45
Glow plugs	
warning lamp.....	29

H

Handbook symbols.....	2
Handbrake.....	49
Headlamps.....	21
bulb changing.....	72–73
bulb specification.....	116
condensation.....	22
driver controls.....	
high beam warning lamp.....	30
removal.....	72
Head restraints	
adjustment.....	14
removing.....	14
Heated screens.....	32
Heated seats.....	33
Heating and ventilation.....	32
driver controls.....	
front.....	32
heated seats.....	33

I

Indicators warning lamp.....	30
Infotainment	
automatic station retune.....	57
controls.....	51, 53
display screen colour.....	54
MP3 file playing.....	61
portable media	
connecting devices.....	60
controls.....	58–59
pairing.....	60
search.....	60
radio controls.....	56
radio controls (standard).....	55
setting the control method.....	60
Instrument panel.....	28
warning lamps.....	29
Interior cleaning.....	78
Interior lamp bulbs.....	76
Interior lamps.....	23
bulb changing.....	72
bulb specification.....	116
types.....	23