

# Audio system

- Short press: to access the audio settings.
    - Subwoofer.
    - Bass.
    - Mid.
    - Treble.
    - Balance.
    - Fade.
    - Loudness.
    - Defeat.
    - Volume.
  - Long press: to access the audio setup menu.
14. Select tuning mode or pause/play the current audio source (CD, MP3, etc).
  15. Release button: Release and remove the audio system face plate for security or to access the system reset button.

## SETTING THE CLOCK

The clock can be set to automatically adjust according to RDS (Radio Data System) information.

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **TUNER**.
3. Select **AUTO CLOCK**.
4. Select **A-CLOCK ON** to enable or **A-CLOCK OFF** to disable.
5. Press and hold **AUDIO/SETUP** to close the setup menu.

## INTERFACE COLOUR

The illumination colour of the audio system can be changed.

1. Press and hold **AUDIO/SETUP** to open the setup menu.