

Audio system

- Short press: to access the audio settings.
 - Subwoofer.
 - Bass.
 - Mid.
 - Treble.
 - Balance.
 - Fade.
 - Loudness.
 - Defeat.
 - Volume.
 - Long press: to access the audio setup menu.
14. Select tuning mode or pause/play the current audio source (CD, MP3, etc).
 15. Release button: Release and remove the audio system face plate for security or to access the system reset button.

SETTING THE CLOCK

The clock can be set to automatically adjust according to RDS (Radio Data System) information.

1. Press and hold **AUDIO/SETUP** to open the setup menu.
2. Select **TUNER**.
3. Select **AUTO CLOCK**.
4. Select **A-CLOCK ON** to enable or **A-CLOCK OFF** to disable.
5. Press and hold **AUDIO/SETUP** to close the setup menu.

INTERFACE COLOUR

The illumination colour of the audio system can be changed.

1. Press and hold **AUDIO/SETUP** to open the setup menu.