

- Trailer direction indicators warning lamp....30
- Transfer gearbox.....45
- range changing on the move.....46
- Transmission
- differential lock.....46
- differential lock wind up.....46
- driver controls.....
- manual.....45
- stationary range changing.....45
- transfer gearbox.....45
- Transporting the vehicle.....104
- Tyre pressure monitoring system (TPMS)
- tyre care.....96
- Tyres
- Indian regulations.....98
- pressures.....97
- replacements.....98
- snow chains.....97
- speed ratings.....96
- tyre care.....96
- tyre wall markings.....95
- wall markings.....95
- wheel and tyre sizes.....97
- U**
- Under body cleaning.....77
- Understeer.....48
- Unlocking.....8
- all doors.....4
- driver's door.....4
- global opening.....4
- mode.....4
- multi point entry.....4
- opening the tailgate.....4
- single point entry.....4
- Used engine oil.....71
- V**
- Vehicle alarm.....69
- Vehicle battery
- effects of disconnection.....90
- electrolyte level.....87
- replacing.....88
- under front seat.....10
- warning symbols.....86
- Vehicle battery care.....86
- Vehicle cleaning
- after driving off-road.....77
- alloy wheels.....77
- interior.....78
- under body.....77
- Vehicle recovery
- lashing points.....104
- towing eyes.....104
- towing on four wheels.....104
- transporting the vehicle.....104
- Vehicle testing on rolling roads.....70
- VIN number.....106
- W**
- Warning lamps.....29
- ABS.....30
- battery charge.....29
- brake.....29
- diesel glow plugs.....29
- diesel particulate filter (DPF).....29
- differential lock.....30
- DPF.....30
- DSC active.....30
- engine malfunction.....29
- headlamp high beam.....30
- indicators.....30
- low fuel.....31
- low oil pressure.....29
- rear fog lamps.....30
- side lights.....30
- trailer direction indicators.....30
- Washer reservoir
- capacity.....114
- Washers.....24
- fluid specification.....84
- fluid top up.....84
- Weights
- gross vehicle weights.....107
- roof load.....107
- roof rack weight.....107
- tow ball/hitch.....37

towing.....	37
vehicle weights.....	107
Wheel changing	
jacking points.....	101
locking wheel nuts.....	99
operating the jack.....	100
recommended process.....	102
safety warnings.....	101
spare wheel.....	99
tilt sensor.....	102
tool kit.....	99
Wheels and tyres	
Indian regulations.....	98
pressures.....	97
replacements.....	98
snow chains.....	97
specified sizes.....	97
tyre care.....	96
tyre speed ratings.....	96
tyre wall markings.....	95
wheel alignment.....	116
Wheel spin.....	48
Windows	
driver controls.....	
operation.....	25
sliding.....	25
sunroof operation.....	26
Windscreens (heated).....	32
Wipers and washers.....	24
driver controls.....	
fluid level.....	84

