


RADIO CONTROLS (STANDARD SYSTEM)



1. Band select/auto store:

- Short press - to switch between bands. Select from **FM1**, **FM2**, **FM3**, **MW** and **LW**.
- Long press - to automatically tune and store 6 Radio Frequencies (RF) as presets.

2. Volume control/menu select:

- Rotate to adjust the volume.
- When a menu is open, rotate to switch between menu items and press to confirm a selection.

3. Information display screen.

4. Preset stations:

- Short press - to select a preset station.
- Long press - to store the current radio frequency.

5. Press and hold to turn on TA (Traffic Announcements).

6. Change the displayed information.

7. Seek up:

- Short press - to auto-seek up the frequency to the next radio station.

- Long press - to seek continuously up through the Radio Frequencies.

8. Seek down:

- Short press - to auto-seek down the frequency to the previous radio station.
- Long press - to seek continuously down through the Radio Frequencies.