
## RADIO CONTROLS (STANDARD SYSTEM)



- 1. Band select/auto store:
  - Short press to switch between bands.
    Select from FM1, FM2, FM3, MW and LW.
  - Long press to automatically tune and store 6 Radio Frequencies (RF) as presets.
- 2. Volume control/menu select:
  - · Rotate to adjust the volume.
  - When a menu is open, rotate to switch between menu items and press to confirm a selection.
- 3. Information display screen.
- 4. Preset stations:
  - Short press to select a preset station.
  - Long press to store the current radio frequency.
- **5.** Press and hold to turn on TA (Traffic Announcements).
- **6.** Change the displayed information.
- **7.** Seek up:
  - Short press to auto-seek up the frequency to the next radio station.

- Long press to seek continuously up through the Radio Frequencies.
- 8. Seek down:
  - Short press to auto-seek down the frequency to the previous radio station.
  - Long press to seek continuously down through the Radio Frequencies.