
## **ELECTRIC WINDOWS**



Before closing a window, care must be taken to make sure that none of the occupants have any part of their body in a position where it could be trapped. Serious injury or death can occur.




Make sure that you remove the starter key when leaving occupants in the vehicle. This will prevent unsupervised operation of the windows, which may result in injury.



With the ignition on, or the engine running:

- Press the lower part of the switch to lower a window.
- Press the upper part of the switch to raise a window.
- Release the switch to stop window movement.

## **SLIDING WINDOWS**



Squeeze either type of lock and slide the window to the desired position. Release the lock and make sure that the catch is located securely into a locking socket.