

washer jets.....	218
Climate control	
air vents.....	75
driver controls.....	
front.....	74
fuel burning heater.....	76
heated and cooled seats.....	76
heated seats.....	75
remote control batteries.....	78
timed climate.....	76
timed climate remote controls.....	78
using the remote control.....	77
Climate seats.....	76
Clock.....	41
Clock settings	
standard audio.....	187
Closing the bonnet.....	205
Closing vehicle sensing.....	64
Clutch	
fluid level.....	222
Clutch and brakes	
adjustment.....	262
Cold weather driving	
diesel particulate filter (DPF).....	203
Compact disc.....	132
Condensation (headlamps).....	52
Conformity declarations.....	182, 270
Connecting jump leads.....	225
Controls	
driving position.....	
overview.....	
standard audio system.....	183
Coolant	
checking the level.....	221
specification.....	221
top up.....	221
Courtesy delay.....	51
Covers	
refitting.....	206
removal.....	206
Critical warning messages.....	45
Cruise control.....	114
ACC driving hints.....	118
ACC emergency braking.....	121

ACC follow mode.....	116
ACC gap change.....	116
ACC radar detection beam issues.....	119
ACC set speed and follow mode	
override.....	117
adaptive cruise control.....	115
adaptive cruise control malfunction.....	119
follow mode.....	116
forward alert in ACC.....	120
resume ACC follow mode.....	118
resume ACC set speed.....	118
using ACC.....	115
warning lamp.....	48
Curtain airbags.....	38

D

DAB radio	
displayed messages.....	189–190
ensembles.....	140, 188
ensemble seek.....	188
manual tuning.....	189
settings.....	139
standard audio.....	188
standard radio presets.....	188
DAB radio controls.....	138
DAB service list.....	189
Data recording.....	256
Daytime running lamps.....	51
Dealer locations.....	175
Declarations of conformity.....	270
navigation system.....	182
Deselecting valet mode.....	73
Destination entry.....	171
postcode.....	174
search area.....	171
Detachable tow ball.....	85
Detection beam issues.....	119
Dialling a number.....	195
Diesel	
filler flap.....	198
fuel.....	197
glow plugs	
warning lamp.....	47
misfuel device.....	198

- sulphur content.....197
- Diesel particulate filter (DPF).....203
 - cold weather driving.....203
 - driving short distances.....203
 - sulphur content.....197
- Dimensions.....264
- Direction indicators.....50
 - warning lamp.....48
- Disability modifications
 - airbags.....40
- Disabling the passenger air bag.....37
- Door mirrors.....60
 - blind spot monitor
 - closing vehicle sensing.....64
 - sensors.....65
- Door transceiver
 - assistance.....68
 - erase all programming.....67
 - garage door opener.....66
 - programming.....66
 - programming a single button.....67
 - programming the garage door opener.....66
 - rolling code device programming.....67
- Double locking.....13
- Drive away locking.....11
- Driver controls.....
- Drive selector
 - malfunction.....95
- Drive selector fails to elevate.....95
- Driving
 - ACC automatic switch-off.....117
 - ACC driving hints.....118
 - ACC emergency braking.....121
 - ACC follow mode.....116
 - ACC forward alert.....120
 - ACC gap change.....116
 - ACC malfunction.....119
 - ACC queue assist.....117
 - ACC radar detection beam issues.....119
 - ACC set speed and follow mode
 - override.....117
 - activating intelligent stop/start.....91
 - adaptive cruise control.....115
 - after a collision.....256
 - arduous conditions.....202
 - before starting.....256
 - blind spot monitor
 - closing vehicle sensing.....64
 - blind spot monitor messages.....65
 - brake control with ABS.....99
 - brakes important information.....99
 - daily checks.....202
 - deactivating intelligent stop/start.....91
 - driver controls.....
 - DSC active warning lamp.....46
 - electronic brake force distribution.....99
 - emergency brake assist.....99
 - forward alert.....120
 - forward alert warning lamp.....48
 - gear shift warning lamp.....48
 - lane departure warning lamp (green).....47
 - lane departure warning lamp (red).....46
 - low oil pressure.....45
 - park assist limitations.....110
 - park assist troubleshooting.....111
 - rain sensor.....57
 - resume ACC follow mode.....118
 - resume ACC set speed.....118
 - running-in.....202
 - selecting park assist.....109
 - sitting correctly.....19
 - steep slope control with ABS.....99
 - using ACC.....115
 - using cruise control.....114
 - weekly checks.....202
- Driving abroad
 - beam pattern.....52
 - headlamps.....52
- Driving aids
 - lane departure warning.....128
 - traffic sign recognition.....127
- Driving position memory.....19
- Driving short distances
 - diesel particulate filter (DPF).....203
- Dual view.....151
 - controls.....151
- Dynamic stability control (DSC).....96
 - DSC active warning lamp.....46