


MANUAL SEATS



⚠ Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

1. Forward and rearward adjustment.
2. Height adjustment.
3. Seatback angle adjustment.
4. Head restraint adjustment (where fitted).