- With the sunroof in the tilted position, briefly press to fully open the sunroof. Press again to stop movement.

The sunroof will operate for 30 seconds after the ignition is turned off, provided that a front door is not opened.

4. Sunroof close switch:

Wherever possible, remove any snow, ice, dirt, and leaves, etc., from the sunroof mechanism, before closing. Failure to do so may damage the sunroof mechanism.

- With the in the sunroof fully open position, briefly press to close the sunroof to the tilted position. Press the again to stop movement.
- With the sunroof in the tilted open, press and hold to close the sunroof. Releasing the switch will stop the sunroof movement.

5. Sun blind:

- To open, push upwards on the textured part of the handle and then, slide the blind into the panel between the sunroof and the headlining.
- To close the sun blind, pull across the aperture until it locks in to place.

ANTI-TRAP PROTECTION

The Anti-trap mechanism does not operate when closing the sunroof from the tilted position. The sunroof can cause serious injury should a body part become trapped. Always make sure that the sunroof is free from obstructions before closing.

Before closing a window or the sunroof, make sure that no occupants have any part of their body in a position where it could be trapped. Even with an Anti-trap system, death or serious injury could occur.

Anti-trap protection will stop window or sunroof movement if an obstruction or resistance is detected. Check the window or sunroof and its aperture, and remove any obstructions (e.g., ice, etc.).

If it is still necessary to raise the window or close the sunroof, the override procedure is as follows:

1. Attempt to close the window/sunroof; Anti-trap will prevent closure and lower the window/open the sunroof slightly.
2. Within ten seconds, attempt to raise the window/close the sunroof again; Anti-trap will prevent closure and lower the window/open the sunroof slightly.
3. Attempt to close the window/sunroof for a third time, this time hold the switch in the close position. Hold until closed.

Note: *If this procedure fails to remove the blockage, the window operation may need to be reset. See* ***203, WINDOW RESET****.*

Note: *The sunroof Anti-trap mechanism works differently and does not require reset, if activated. See* ***203, SUNROOF RESET****.*