


ELECTRIC WINDOWS



E155548

- !** To prevent accidental operation, never leave the Smart key in the vehicle if children or animals are also left in the vehicle.

1. Window switches:

The windows will operate for 5 minutes after the engine is switched off, as long as none of the doors are opened.

All 4 windows have a one-touch operation. Briefly pull the switch up fully and release; the window will continue to raise until fully closed. Briefly press the switch down fully and release, the window will continue to lower until fully open. Pressing or pulling the switch again will stop the window.

2. Rear window isolator button:

- !** If children are carried in the rear seats, the isolator switch should be used to prevent operation of the windows. If the windows are operated by young children, there is a risk of serious injury or death.

3. Sunroof open switch:

- !** To prevent accidental damage, make sure any roof rack load will not interfere with the opening of the sunroof.

- With the sunroof closed, briefly press to open the sunroof to the tilted position.