

For information on the CD/DVD loading slot and eject button, and the use of the audio/video controls on the audio unit and steering wheel, see **134, AUDIO/VIDEO CONTROLS**.

### **VIDEO MEDIA INHIBIT WITH VEHICLE MOVING**

When the vehicle is moving, the video picture will automatically be inhibited. The Touch screen will display the **TV/My video** screen and the relevant safety message will be displayed.

### **FULL SCREEN VIEW**

When Full screen mode is selected, the Seek controls operate in the same manner as they do in Preview mode.

Use the relevant soft key to select the **4:3, 16:9** or **Zoom** option to magnify the picture.