5. Leave the Smart key in a secure place inside the vehicle.
6. Release the EPB before towing the vehicle.

Leaving the ignition switched on for extended periods will drain the vehicle battery.

AFTER TOWING ON FOUR WHEELS

1. Apply the Electric Parking Brake (EPB).
2. Switch on the ignition and press the brake pedal.
3. Rotate the gear selector to the Park (**P**) position.
4. Deactivate the Transmission park release. See **247, TRANSMISSION PARK RELEASE**.
5. Switch off the ignition, and remove the Smart key from the vehicle.
6. Remove the recovery vehicle towing attachment from the front towing eye and refit the cover.

Use extreme caution when detaching towing equipment. Vehicle movement is possible which can result in serious injury.