power steering
check....211
specification....211
top up....211
specifications....252
washer fluid....212
check....212
specification....212
Fog lamp
bulb replacement....198
Fog lamps
warning lamps
front....45
rear....45
Follow
override....113
Follow mode
entering....112
gap change....113
gap changing....113
override....114
resume....114
Forward alert....115
Forward alert in ACC
object detection....115
Forward alert warning lamp....46
Front airbags....36
Front climate control....68
automatic recirculation....69
Front parking aids....104
system fault....105
Front wipers....51
Fuel and refuelling....187
consumption....189
diesel....185
diesel fuel sulphur content....185
ethanol....184
filler flap....187
fuel filler flap....186
fuel specification....184
methanol....185
methyl tertiary butyl ether (MTBE)....185
misfuel device....187
octane rating....184
petrol....184
running out....185
safety precautions....184
tank capacity....187
water in fuel....187
Fuel burning heater....70
Fuel consumption....189
combined cycles....190
extra-urban cycle....190
urban cycle....190
Fuel filler flap....186
Fuel gauge....39
Fuel system....193
Fuel tank
capacity....254
Full screen view for video....154
Fuses
changing....218
engine compartment fuse box....219
locations....218
passenger compartment fuse box....220

G

Garage door opener....60
assistance....62
entry gate....61
erase all programming....61
programming....60
programming a rolling code device....61
programming a single button....61
Gearbox
automatic....94
driver controls....
emergency park release....247
hill descent....96
range change indicators....96
range changing....97
stationary range changing....96
transfer gearbox....96
General program....117
Global closing....10
Global opening....6
Glow plugs
warning lamp....44