Rear wiper

The frequency of the intermittent rear wiper will increase when the vehicle's speed increases.



This feature can be enabled/disabled by your Dealer/Authorised Repairer.

RAIN SENSOR

The Rain sensor (if fitted) is mounted on the inside of the windscreen, behind the rear-view mirror. The sensor is able to detect the presence and amount of water on the windscreen and automatically activate the windscreen wipers accordingly.

Note: *Static droplets may not be detected on the initial start-up. A single wipe should be used to clear the windscreen.*

To activate the Rain sensitive wipers, move the wiper/washer control to the **AUTO** position (**1**). The behaviour of the system may be adjusted to the driver's preference by rotating the collar (**2**).

Note: *In dry and often sunny conditions, optical influences and dirt accumulation on the windscreen may result in the windscreen wipers activating inadvertently. To prevent this, it is recommended that, under these conditions, the wiper/washer controls are returned to the* ***OFF*** *position.*

HEADLAMP WASHERS

If the headlamps are on, and there is sufficient liquid in the washer reservoir, operating the screen wash will also power wash the headlamps.

The headlamp power wash will operate on every fifth operation of the screen washer, provided the headlamps are still switched on and approximately 10 minutes have elapsed since the last headlamp wash.

Switching the headlamps or ignition off and back on again, will reset the cycle.

Note: *The headlamp washers are inhibited when the washer fluid reservoir level is low.*