

# Entering the vehicle

- When approaching the vehicle during darkness, press to switch on the approach illumination. Press again to turn the approach lamps off.
  - The approach illumination period, set at the factory, is 30 seconds. This delay period may be configured to provide illumination lasting between 0 and 180 seconds.
6. Smart key emergency key:
- Slide and remove the cover to expose the emergency key.
  - Remove the emergency key and unfold.
7. If the Smart key fails to open the vehicle:
- Insert the emergency key into the slot at the base of the door lock cover. Gently lever upwards and twist to release the cover from the retaining clips.
  - Insert the emergency key into the exposed lock to operate.

**To lock:** Make sure that all of the doors and the tailgate are closed, then turn the key towards the front of the vehicle and release. This will lock the doors but will not arm the alarm.

**To unlock:** Turn the key towards the rear of the vehicle and release. If the security system is disarmed, all of the doors and the tailgate will be unlocked. If the security system is armed, only the driver's door will unlock.

If the vehicle is unlocked using the emergency key with the security system armed, the alarm will sound when the door is unlocked. The alarm will continue to sound until the Smart key is positioned correctly, see **90, KEYLESS START BACKUP**.

**Note:** A replacement Smart key can only be obtained from your Dealer/Authorised Repairer. The Dealer/Authorised Repairer will require proof of ownership.

Notify your Dealer/Authorised Repairer immediately if a Smart key is lost or stolen.

**Note:** The fuel filler flap can only be opened when the vehicle is unlocked.

## GLOBAL OPENING

Press and hold the unlock button for 3 seconds to unlock the vehicle and open all of the windows.

To cancel Global opening, press any of the buttons on the Smart key or operate the driver's window switch. To stop a particular window opening, operate the relevant window switch.

This feature can be enabled/disabled via the **Vehicle Set-up** menu (see **40, INSTRUMENT PANEL MENU**).

## KEYLESS ENTRY



**Any person fitted with an implanted medical device should make sure that the device is kept at a distance of at least 22 cm (8.7 inches) away from any transmitter mounted in the vehicle. This is to avoid any possibility of interference between the system and the device. For information concerning the locations of the security system transmitters, see 260, SMART KEY TRANSMITTER LOCATIONS.**



If a remote control is lost, a replacement can be obtained and programmed to the vehicle by a Dealer/Authorised Repairer. Notify a Dealer/Authorised Repairer as soon as a remote control is lost or stolen and have the remaining remote control(s) reprogrammed.