

- 7. ON:** Rear wiper intermittent operation. Frequency increases with vehicle speed.
- 8.** Rear window wash/wipe: Press and release to operate the rear washer and wiper. The wiper will operate in a set cycle, to minimise drips when the button is released. If more washer fluid is required, push and hold the button.

Note: When Reverse (R) gear is selected and the front wipers are operating, the rear wiper will activate.

Note: The rear wiper will not operate while the tailgate is open.



Drip wipe on the windscreen can be enabled/disabled by a Dealer/Authorised Repairer.

Vehicles without rain sensor fitted:

- 1.** Intermittent wipe: The time delay between wipes can be adjusted by rotating the collar (2).



Make sure the wipers are switched off before entering a car wash. If the wipers operate during the car washing process, damage may occur to the wiper mechanism.

- 2.** Rotate the collar to adjust the time delay between wipes when position (1) is selected. The higher the setting, the more frequently wipes occur.

Note: Wipe frequency will increase with vehicle speed.

- 3.** Low speed continuous wipe.
- 4.** High speed continuous wipe.
- 5.** Single wipe of the windscreen, or hold down for further continuous wipes.

- 6.** Windscreen wash/wipe: Pull and release to operate the front washers and wipers. The wipers will operate for 2 further wipes after the control is released. After a few seconds, a drip wipe will clear any residual washer fluid from the windscreen. If more washer fluid is required, pull and hold the control position.

- 7. ON:** Rear wiper intermittent operation. Frequency increases with vehicle speed.

- 8.** Rear window wash/wipe: Press and release to operate the rear washer and wiper. The wiper will operate in a set cycle, to minimise drips when the button is released. If more washer fluid is required, push and hold the button.

Note: When reverse (R) gear is selected and the front wipers are operating, the rear wiper will activate.

Note: The rear wiper will not operate while the tailgate is open.



Drip wipe on the windscreen can be enabled/disabled by a Dealer/Authorised Repairer.

SPEED-DEPENDENT MODE

Front wipers

If the vehicle's speed drops below 8 km/h (5 mph) with the wipers operating, the wipers will switch to the next lowest speed. When the vehicle's speed increases to over 8 km/h (5 mph), the original wiper speed setting will be restored automatically.

Vehicles without a Rain sensor fitted will also increase the frequency of the intermittent front wipe when the vehicle's speed increases.



This feature can be enabled/disabled by your Dealer/Authorised Repairer.