



CHANGING A BULB

-  Before attempting a bulb change, make sure that the ignition and the affected lamp are turned off.
-  Always replace bulbs with the correct type and specification. If you are in any doubt, contact your Dealer/Authorised Repairer for advice.

Note: In certain territories, it is a legal requirement to carry spare bulbs. A replacement bulb kit is available as an approved accessory from your dealer.

Note: After replacing a headlamp bulb, headlamp alignment should be checked with the appropriate equipment.

Note: Some vehicles are fitted with LED units, these cannot be serviced.