tyres....225
Previous destination....175
Programming the timed climate....70
Punctured tyres....227
Puncture repair kit....232
instructions for use....232
repair procedure....233
safety....232

Q

Quick POI selection....174

R

Radio
automatic station retune....141
controls....140
DAB
settings....143
stations....144
DAB controls....142
Radio (Standard)....127
adaptive volume control....124
alternative frequencies....125
bass and treble setting....124
cancelling an announcement....126
controls....123
DAB ensemble seek....127
DAB messages....129
DAB radio manual tuning....128
DAB radio presets....127
DAB service list....128
news information....126
preset buttons....125
station autostore....124
station lock....125
switching off traffic information....126
traffic announcement volume....126
traffic information....126
Radio data system auto retune....141
Radio frequency regulations....261
Rain sensor....53
Range changing....96–97
indicators....96
RDS
news information....126
switching off traffic information....126
TMC
display....177
icons....178
overview....177
traffic information....126
Rear camera
hitch guidance....80
parking aids....105
reverse traffic detection....107
sensors....108
Rear climate control....70
Rear fog lamps warning lamp....45
Rear lamp
bulb changing....200
removal....200
Rear media
headphones....157
remote control batteries....158
remote control use....156–157
touch screen control....155
Rear seats
folding....16–17
raising....16–17
third row....18
third row folding and raising....19
Rear window blind....63
Recommended tyre pressures....231
Recording
event data....250
service data....250
Recovery
off-road....245
towing eyes....245
towing on four wheels....248–249
transmission park release....247
Refuelling
diesel....185
diesel fuel sulphur content....185
ethanol....184
fuel filler flap....186
methanol....185