
REVERSE TRAFFIC DETECTION



The Reverse Traffic Detection (RTD) system is a supplement to, not a replacement for, safe driving, good observation, and use of the exterior and rear-view mirrors.

Note: *RTD is automatically disabled when a trailer is connected and when Park assist is active.*

In addition to the functionality provided by the rear camera, the RTD system provides a warning to the driver of any moving vehicle, at either side, that may pose an accident risk during a reversing manoeuvre.

An amber warning icon (**1**) will flash in the relevant exterior mirror and an audible warning will be emitted to indicate the presence of a moving vehicle. The rear camera screen (**2**) or the Parking aid screen (**3**) will also show a warning on the relevant side(s) of the screen. To switch between the rear-view camera and the Parking aid screen, touch the camera image or the **Rear Camera** icon accordingly.

The system can be enabled or disabled via the Instrument panel menu. See **40, INSTRUMENT PANEL MENU**. When RTD is disabled, an amber dot (**4**) will be displayed in both exterior mirrors.