Follow the steps illustrated. Insert a new bulb and refit the components.

- 1. Sun visor lamps.
- 2. Courtesy lamp and map lamps.
- 3. Load space lamp.
- 4. Puddle lamps.
- 5. Glove box lamp.
- 6. Footwell lamps.

WINDOW RESET

The windows will need to be reset if the battery is disconnected, becomes discharged, or the power supply is interrupted.

Reset as follows:

- 1. Close the window fully.
- 2. Release the switch, then lift it to the close position and hold for 1 second.
- 3. Repeat the procedure on each window.

SUNROOF RESET

If the battery is disconnected, or the power supply is interrupted while the sunroof is partially open, it will need to be recalibrated.

Once the battery is reconnected, or the power supply is restored, recalibrate the sunroof as follows:

- 1. Switch the ignition on.
- 2. With the sunroof closed, press and release the front of the switch. The sunroof will move to the tilted position.
- **3.** Press the front of the sunroof switch and hold for 20 seconds.
- After 20 seconds, the sunroof will begin to move. Keep the front of the switch pressed until the fully open/close cycle has completed.
- 5. Once the sunroof has stopped moving, release the switch.

The sunroof can now be operated as normal.

PARTS AND ACCESSORIES

 \mathbb{A}

- The fitting of non-approved parts and accessories, or the carrying out of non-approved alterations or conversions, may be dangerous and could affect the safety of the vehicle and occupants, and also invalidate the terms and conditions of the vehicle's warranty.
 - Land Rover will not accept any liability for death, personal injury, or damage to property, which may occur as a direct result of fitment of non-approved accessories or the carrying out of non-approved conversions to Land Rover vehicles.