

Note: If a listed item is longer than the available space on the menu, ...> will appear. Use the seek controls on the steering wheel to view the entire entry. See **82, AUDIO/VIDEO CONTROLS**.

VOICE TUTORIAL

To listen to a tutorial detailing the operation of the Voice system:

1. Briefly press the Voice button to start a voice session.
2. Wait for the tone to sound, then say **Voice tutorial**.

Alternatively, the tutorial can be selected using the Touch screen, as follows:

1. Select **Setup** from the Touch screen **Home menu**, or press the **SETUP** button on the Instrument panel..
2. Select **Voice** from the Setup menu.
3. Select **Operating guide** from the Voice settings menu.
4. Select **Voice tutorial**.

The voice tutorial can be cancelled, at any time, by touching the on-screen pop-up or by pressing and holding the Voice button.

VOICE TRAINING

This is a feature designed to enable the system to better recognise the vocal characteristics of a user, once the training has been completed. To carry out Voice training:

1. Select **Setup** from the Touch screen **Home menu**, or press the **SETUP** button on the Instrument panel.
2. Select **Voice** from the **Setup** menu.
3. Select **Voice training** from the Voice settings menu.
4. Select **User 1** or **User 2**, to start the training.

5. Follow the on-screen and audible instructions.

The training session can be cancelled, at any time, by touching the on-screen pop-up or by pressing and holding the Voice button.

VOICETAGS

Voicetags enable the user to personalise the Voice system so that a single name can be used to call up a navigation destination, telephone number, or radio channel.

To add a Voicetag:

1. Briefly press the Voice button to start a voice session.
2. Wait for the tone to sound and then say **Phone, Navigation, or Radio**.
3. Say **Store voicetag**.

Alternatively, Voicetags can be managed through the Touch screen as follows:

1. Select **Setup** from the **Home menu**, or press the **SETUP** button on the Instrument panel.
2. Select **Voice** from the Setup menu.
3. Select **Voicetags** from the Voice settings menu.
4. Select the system which the Voicetag is to activate (**Phone, Navigation, or Radio/DAB**).

Follow the on-screen and audible instructions.