

## ENGINE COMPARTMENT FUSE BOX

Fuse number	Rating (Amps)	Fuse colour	Circuits protected
F1	-	-	-
F2	5	Tan	Voltage module
F3	80	Clear	Cooling fans
F4	60	Blue	Glow plugs (diesel only)
F5	-	-	-
F6	15	Blue	Engine management. Oxygen sensors
F7	5	Tan	Relays
F8	20	Yellow	Engine management
F9	10	Red	Engine management
F10	15	Blue	Automatic transmission
F11	10	Red	Engine management
F12	15	Blue	Engine management
F13	10	Red	Air conditioning
F14	15	Blue	Engine management. Air conditioning
F15	40	Orange	Starter motor
F16	100	Violet	Electric booster heater (diesel only)
F17	60	Blue	Passenger compartment fuse box supply
F18	60	Blue	Passenger compartment fuse box supply
F19	60	Blue	Luggage compartment fuse box supply. Audio system
F20	60	Blue	Luggage compartment fuse box supply
F21	60	Blue	Luggage compartment fuse box supply
F22	30	Green	Windscreen wipers

# Fuses

Fuse number	Rating (Amps)	Fuse colour	Circuits protected
F23	40	Orange	Passenger compartment fuse box supply
F24	-	-	-
F25	30	Green	Anti-lock Braking System (ABS)
F26	40	Orange	ABS
F27	40	Orange	Passenger compartment fuse box supply
F28	40	Orange	Heater blower
F29	-	-	-
F30	15	Blue	Headlamp washer
F31	15	Blue	Horns
F32	20	Yellow	Auxiliary heater (diesel only)
F33	5	Tan	Relays
F34	40	Orange	Heated windscreen (left side)
F35	40	Orange	Heated windscreen (right side)
F36	5	Tan	Auxiliary heater water pump (diesel only)
F37	20	Yellow	Fuel pump
F38	10	Red	Parking aid module
F39	-	-	-
F40	-	-	-
F41	-	-	-
F42	5	Tan	Headlamp levelling control
F43	5	Tan	Automatic high beam. Rear camera
F44	10	Red	Heated steering wheel
F45	5	Tan	Auxiliary heater water pump (diesel only)