

- TPMS pressure compensation.....182
  - tyre care.....179
  - tyre repair safety.....186
  - tyre wall markings.....178
  - use of spare tyre.....192
  - valves.....180
  - wall markings.....178
  - winter.....181
- U**
- Under body cleaning.....156
  - Under bonnet covers.....147
  - Understeer.....71
  - Unlocking.....9
    - all doors.....4
    - driver's door.....4
    - global opening.....4
    - mode.....4
    - multi point entry.....4
    - single point entry.....4
  - USB devices
    - connecting multiple devices.....96
  - Used engine oil.....144
  - Using cruise control.....77
  - Using the parking aids.....74
  - Using the spare tyre
    - important information.....192
- V**
- Valet mode.....53
    - deselecting.....53
  - Vehicle alarm.....142
  - Vehicle battery
    - connecting jump leads.....165
    - effects of disconnection.....168
    - replacing.....167
    - warning symbols.....164
  - Vehicle battery care.....164
  - Vehicle build date.....197
  - Vehicle cleaning
    - after driving off-road.....156
    - airbag covers.....158
    - interior.....157
    - under body.....156
    - washer jets.....147
  - Vehicle data recording.....196
  - Vehicle recovery
    - off-road.....194
    - steering column lock.....6
    - towing eyes.....193
    - towing on four wheels.....194–195
    - transmission park release.....194
  - Vehicle testing on rolling roads.....143
  - Video media player
    - controls.....99
    - full screen view.....100
    - inhibited display.....100
  - VIN number.....197
  - Voice control.....101
    - navigation POI categories.....103
    - recognising your voice.....102
    - settings
      - command list.....52
      - operating guide.....52
      - preferences.....52
      - voicetags.....52
      - voice training.....52
    - training the system.....102
    - tutorial.....102
    - voicetags.....102
  - Voice guidance.....116
  - Volume
    - telephone.....108
- W**
- Warning lamps.....34, 36
    - ABS.....35
    - airbags.....28, 36
    - battery charge.....34
    - brake.....34–35
    - critical warning message.....34
    - cruise control.....37
    - diesel glow plugs.....35
    - DSC active.....35
    - engine/transmission.....35
    - external temperature.....36
    - gear shift warning lamp.....36