

- petrol.....137
 - running out.....138
 - safety precautions.....137
 - tank capacity.....140
 - Fuel burning heater.....56
 - Fuel consumption.....141
 - combined cycles.....141
 - extra-urban cycle.....141
 - urban cycle.....141
 - Fuel filler flap.....139
 - Fuel gauge.....31
 - Fuel system.....144
 - Fuel tank
 - capacity.....200
 - Full screen view for video.....100
 - Fuses
 - changing.....170
 - engine compartment fuse box.....171
 - locations.....169
 - luggage compartment fuse box.....177
 - passenger compartment fuse box.....173
- ## G
- Garage door opener.....46
 - assistance.....48
 - entry gate.....47
 - erase all programming.....47
 - programming.....46
 - programming a rolling code device.....47
 - programming a single button.....47
 - Gearbox
 - automatic.....69
 - driver controls.....
 - emergency park release.....194
 - fault.....70
 - gear shift warning lamp.....36
 - hill descent.....70
 - manual.....70
 - General program.....78
 - Global closing.....8
 - Glow plugs
 - warning lamp.....35
 - Gradient release control
 - ascent brake release.....81
 - Grass/gravel/snow.....78
- ## H
- Handbook symbols.....2
 - Handbrake.....73
 - Headlamps.....38
 - beam pattern.....39
 - bulb change.....149
 - bulb changing.....147
 - bulb identification.....148
 - bulb specification.....203
 - condensation.....39
 - daytime running lamps.....38
 - driver controls.....
 - driving abroad.....39
 - high beam warning lamp.....36
 - levelling.....39
 - removal.....148
 - washers.....43
 - xenon.....148
 - Head restraints.....15
 - Heated screens.....56
 - Heated seats.....56
 - Heated steering wheel.....16
 - Heating and ventilation.....54–55
 - auto setting.....55
 - driver controls.....
 - fuel burning heater.....56
 - heated seats.....56
 - manual.....54
 - timed climate.....56
 - Hill descent control.....80
 - brake release control.....81
 - brake temperature.....81
 - operation.....80
 - selecting.....80
 - system fault.....81
 - warning lamp.....37
 - warning messages.....81
 - Home (navigation).....116
 - Homelink.....46
 - assistance.....48
 - erase all programming.....47
 - gate/door opener.....47