

- standard radio presets.....130
  - DAB radio controls.....90
  - DAB service list.....131
  - Data recording.....196
  - Daytime running lamps.....38
  - Dealer locations.....118
  - Declarations of conformity.....207
    - navigation system.....125
  - Deselecting valet mode.....53
  - Destination entry.....114
    - postcode.....116
    - search area.....114
  - Diesel
    - filler flap.....139
    - fuel.....138
    - glow plugs
      - warning lamp.....35
    - misfuel device.....139
    - sulphur content.....138
  - Diesel particulate filter (DPF).....143
    - cold weather driving.....143
    - driving short distances.....143
    - sulphur content.....138
  - Dimensions.....202
  - Direction indicators.....38
    - warning lamp.....36
  - Door mirrors.....44
  - Door transceiver
    - assistance.....48
    - erase all programming.....47
    - garage door opener.....46
    - programming.....46
    - programming a single button.....47
    - programming the garage door opener.....46
    - rolling code device programming.....47
  - Double locking.....8
    - full alarm.....8
  - Drive away locking.....6
  - Driver controls.....
  - Driving
    - activating intelligent stop/start.....68
    - after a collision.....196
    - arduous conditions.....142
    - before starting.....196
    - brake control with ABS.....72
    - brakes important information.....72
    - daily checks.....142
    - deactivating intelligent stop/start.....68
    - driver controls.....
    - DSC active warning lamp.....35
    - electronic brake force distribution.....72
    - emergency brake assist.....72
    - gear shift warning lamp.....36
    - low oil pressure.....34
    - rain sensor.....43
    - sitting correctly.....12
    - steep slope control with ABS.....72
    - using cruise control.....77
    - weekly checks.....142
  - Driving abroad
    - beam pattern.....39
    - headlamps.....39
  - Driving position memory.....13
  - Driving short distances
    - diesel particulate filter (DPF).....143
  - Dynamic stability control (DSC).....71
    - DSC active warning lamp.....35
    - DSC off warning lamp.....35
    - switching off.....71
    - switching on.....71
- ## E
- Easy route.....115
  - Effects of battery disconnection.....168
  - Electric parking brake.....73
  - Electric seats.....11
    - position memory.....13
    - restricted seat travel.....12
  - Electric windows
    - operation.....49
  - Electronic brake force distribution.....72
  - Electronic data.....196
  - Emergency (navigation).....117
  - Emergency brake assist.....72
  - Engine
    - antifreeze level.....160
    - compartment opening.....144
    - compartment overview.....146