

DRIVER CONTROLS

For further information on the numbered item, refer to the page number.

1. Roof blind switch. See **71**.
2. Front interior courtesy lamp. See **55**.
3. Front map/reading lamps. See **55**.
4. Breakdown call button.
5. SOS emergency call button.
6. Exterior lamps and Trip computer control. See **51** and **43**.
7. Audio/Video system control. See **132**.
8. Instrument panel and Message centre. See **41**.
9. Instrument panel menu control. See **42**.
10. Wipers and washers control. See **57**.
11. START/STOP button. See **91**.
12. Touch screen display. See **72**.
13. Audio system. See **132**.
14. Hazard warning lamps switch.
15. Heating, ventilation and air conditioning controls. See **76**.
16. Intelligent stop/start button. See **93**.
17. Hill Descent Control (HDC) button. See **126**.
18. Dynamic Stability Control (DSC) button. See **98**.
19. Automatic transmission gear selector. See **95**.
20. Terrain Response control. See **124**.
21. Manual transmission gear selector. See **97**.
22. Electric parking brake. See **102**.
23. Audio on/off/volume control. See **132**.
24. Upshift gear paddle. See **95**.
25. Adaptive cruise control buttons. See **117**.
26. Cruise control or Adaptive cruise control buttons. See **116** and **117**.
27. Steering column adjustment lever. See **25**.
28. Horn.
29. Telephone and voice control buttons. See **164**.
30. Headlamp levelling control. See **53**.
31. Interior lamp illumination control. See **56**.
32. Bonnet release lever. See **207**.
33. Lane departure warning button. See **130**.
34. Tailgate release/open button. See **10**.
35. Heated steering wheel button. See **25**.
36. Downshift gear paddle. See **95**.
37. Rear window isolator switch. See **70**.
38. Window switches. See **70**.
39. Mirror adjustment/power-folding control. See **61**.
40. Central locking/unlocking buttons. See **16**.
41. Driving position memory buttons. See **19**.

